Contents

The Quick Guide is not intended as a substitute for your *Owner's Manual*. We strongly encourage you to review the *Owner's Manual* and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Air Conditioning System
- Basic operation 33
- Using the automatic mode 34
- Adjusting the temperature in DUAL mode 34

Ashtrays 37
Audio System
- Basic operation 35
- Listening to the radio 36
- Playing the CD/DVD player 36

AVS (Adaptive Variable Suspension System) 24
Compass 41
Console Box 39
Cruise Control 22
Cup Holders 40
Door Locks 49
Driving Position Memory System 12
Dynamic Radar Cruise Control 23
Emergency Flasher Switch 20
Fog Lights 27
Fuel Tank Cap 51
Garage Door Opener 43
Glove Box 40
Hands-free System (For Cellular Phone) 37
Headlight Cleaner 30
Headlights 26
Head Restraints 13
Hood 51
Inside Rear View Mirror 15

Instrument Panel Light Control 30
Interior Lights 41
Intuitive Parking Assist 21
Keys 8
Lexus Enform with Safety Connect 47
Luggage Mat 42
Mode Select Switch 20
Moon Roof 50
Multi-Information Display 19
Odometer/Trip Meter and Trip Meter Reset Buttons 16
Outside Rear View Mirrors 15
Overview 3
Parking Brake 18
Power (ignition) switch 17
Power Windows 50
Rear Sunshade 41
Rear Window and Outside Rear View Mirror Defoggers 30
Safety Connect 45
Seat Belts 14
Seat Heaters/Ventilators 38
Seats 11
Smart Access System with Push-button Start 9
Steering Wheel 16
Theft Deterrent System 10
Touch Screen 31
TRAC/VSC Off Mode 25
Transmission 18
Trunk 52
Turn Signal Lever 20
Windshield Wipers and Washers 28

Depending on specifications, the vehicle shown in the illustration may differ from your vehicle in terms of color and equipment.

Overview
Instrument Panel
Headlight switch P.26
Turn signal lever P.20
Fog light switch P.27
Windshield wipers and washer switch P.28
Multi-information display P.19
See P.5
Driving position memory switches P.12
Inside door lock button P.49
Window lock switch P.50
Power window switches P.50
Door lock switch P.49
A
B
See P. 6
Trunk opener P.52
Parking brake pedal P.18
Hood lock release lever P.51
Fuel filler door opener P.51

Power (ignition) switch P.17
Audio system P.35
Air conditioning system P.33
Rear window and outside rear view mirror defoggers P.30
Security indicator P.10
Glove box P.40
Trunk opener main switch P.52
Emergency flashers P.20
See P.7
C
ILYQ0S168

Overview
Instrument Panel
A
Headlight cleaner switch* P.30
Rear sunshade switch* P.41
Intuitive parking assist switch* P.21
"AFS OFF" switch P.26
PUSH
MAX
MODE
L R
MIRROR
ODO TRIP
RESET
ILYPS023
Instrument panel light control P.30
Odometer/trip meter and
trip meter reset buttons P.16
Outside rear view mirror switches P.15

B
“DISP” switch P.19
Telephone switch P.37
DISP
MODE
ILYQ0S004
Tilt and telescopic steering control switch P.16
Distance switch* P.23
Cruise control switch P.22, 23
*: If equipped

Overview
Instrument Panel
C
Seat heater/ventilator switches*
P.38
Cup holders P.40
Shift lever P.18
Ashtray P.37
LYPS167
AVS switch P.24
Mode select switch P.20
VSC OFF switch P.25
* : If equipped